## fast frame system assembly

Just follow these simple instructions. No special tools required.





- a. 4 Frame Corners
- b. 4 Frame Panels
- c. 1 Flexible Graphic Panel

Inspect the contents of your Fast Frame.

Layout all parts on a flat surface.

Build out the *Fast Frame* by laying out the four frame panels (b) in the required shapes.



Insert corner connectors (a) into frame panels (b) as shown to create a solid frame.



Insert flexible graphic panel by guiding the beading into the specially designed channel.



Your Fast Frame is now complete. Graphic panels can be easily removed and replaced any time you wish. Frames can be stored fully assembled, or detached and stored in a compact reusable carton.